

## PUNTERAS INYECCION

<p><b>1003</b></p>  <p><b>BOSCH MPI BLANCO</b></p> <p>1003</p>	<p><b>1011</b></p>  <p><b>MARELLI MPI NEGRO</b></p> <p>1011</p>	<p><b>1012</b></p>  <p><b>MARELLI MPI AZUL</b></p> <p>1012</p>	<p><b>1014</b></p>  <p><b>BOSCH MPI VERDE</b></p> <p>1014</p>	<p><b>1303</b></p>  <p><b>BOSCH MPI</b></p> <p>1303</p>
<p><b>1306</b></p>  <p><b>TOYOTA</b></p> <p>1306</p>	<p><b>1307</b></p>  <p><b>CORSA-VECTRA-S10 D/99</b></p> <p>1307</p>	<p><b>1318</b></p>  <p><b>CHEVROLET MPI</b></p> <p>1318</p>	<p><b>1319</b></p>  <p><b>FORD EXPLORER</b></p> <p>1319</p>	